

EVAKOOL®

INSTRUCTION MANUAL

FOR MODELS

EVAKOOL HEAVY DUTY FRIDGE
SLIDE - EKFS-SML

EVAKOOL HEAVY DUTY FRIDGE
SLIDE - EKFS-LGE



CHILLED FOR GOOD TIMES

For technical or warranty support please contact:

T: 1300 385 665 - 1300 EVKOOL

E: warranty@evakool.com

W: www.evakool.com.au

PARTS LIST

- 1 x Fridge Slide
- 6 x M6 Washers
- 6 x M6 Tee Nuts
- 6 x M6 20mm Bolts (with 3mm Allen Key head)

What you'll need to complete the install:

- | | |
|-------------------|--|
| 1 x Drill | 1 x Hammer |
| 1 x 7mm Drill Bit | 1 x Permanent Marker |
| 1 x 3mm Allen Key | 1 x Friend (not a requirement but will make your job a lot easier) |

INSTALLATION GUIDE:

1. Place the fridge on the surface you wish to install it on.
2. Open the slide by opening the metal locking tab and depressing the lock lever on the right. Pull the slide forwards to reveal the fixing holes in the base of the slide.
* Hint: You might want to grab a friend to help you with this step as the fridge slide will tip forward when the slide is extended until it is secured in place.
3. Mark 6 of the 11 fixing holes on the base of the slide with a permanent marker as drilling points.
* Tip: You do not have to use all 11 holes. There are 11 holes available to suit a variety of setups. Please evenly space the 6 drilling points across the base of the slide.
4. Close the slide by depressing the lock lever on the right and pushing the slide backwards into a closed position. Close the locking tab in place and remove the fridge slide.
5. Drill 6 holes as per your permanent marker drilling points with a 7mm drill bit.
6. Insert the 6 x M6 Tee Nuts into the 6 holes you have drilled. Please ensure that the Tee Nuts are upright and square and then hammer them in securely.
7. Reposition the fridge slide where required and complete the installation by screwing in 6 x M6 20mm Bolts and 6 x M6 Washers (supplied) securely into the Tee Nuts.
* Hint: You might want to grab a friend to help you with this step as the fridge slide will tip forwards when the slide is extended until it is secured in place.

IMPORTANT NOTES: PLEASE READ BEFORE INSTALL

- We recommend a minimum 12mm thick timber top for installing your fridge slide.
- Prior to fitting a fridge to your fridge slide, the slide must be securely and evenly bolted down to the floor of the vehicle or wherever the fridge slide is to be used.
- Under no circumstances should the fridge slide be used other than when it is fixed down correctly on a smooth, even surface, with no contortion to the frame.
- The sliding tray is activated by opening the metal locking tab and depressing the right hand side lever on the front of the fridge slide to pull forward. The fridge slide will lock into place at ½ and full extension.
- Do not apply excessive pressure or force when using the lever as it will damage the lever and locking mechanism of the slide.
- When closing the fridge slide, ensure that the tray firmly locks into place and close the locking tab.
- This product is designed to carry portable 12V fridges with a total load capacity of 125KG. This product is intended for recreational use only and should not be used for commercial purposes. Using this product for commercial purposes will void any applicable warranty periods.