

DELUXE SELF INFLATING MAT PUMPSACK INSTRUCTIONS

The BlackWolf Deluxe range of mattresses include a pump sack for inflating the mattress. Your mat is self inflating but if you get to camp late and don't have time to let your mat inflate by itself the pump sack can be used to add extra air to your mat. Your pumpsack is also the storage bag for your mat.

How to use the pumpsack:

Step 1

Unroll your mat inside your tent

Step 2

Open the valve cap and orange valve insert the mat will begin inflating itself.

Step 3

To add extra air to your mat with your pumpsack install the orange valve insert in the INFLATE position then remove the valve cover from under the handle on the base of the bag (picture A) then push the socket in the pumpsack over the orange valve cap (picture B). It is important that the bag and mat connect tightly so that no air can escape. The orange valve will only allow air to pass in one direction so the mat will not deflate while you are inflating the mat.

Step 4


To inflate the bag, hold the pumpsack open so it is full of air (picture C) then roll from the opening of the bag, as you roll the air will be pushed from the pumpsack into the mat through the one way valve (picture D).

Repeat this action until your mat is fully inflated.

Step 5

Detach the pumpsack and close the top cap on the valve.

Note: It is better to use the pumpsack to add extra air to you mat rather than blowing it up with your mouth because moisture in your breath will go into your mat which may encourage mould to grow or in cold environments may freeze. If you do blow your mat up by mouth make sure you air the mat out for a couple of days when you get home fully inflated with both valves open, ideally you should also store your mat inflated with the valves open.



BLACK WOLF

ESCAPE | EXPLORE | DISCOVER